

For vehicles with a navigation system, refer to the “Navigation System Owner’s Manual” for information regarding the equipment listed below.

- Navigation system
  - Air conditioning controls
  - Windshield wiper de-icer
  - Rear view monitor system
- Intuitive parking assist
  - Audio/video system
  - Rear window and outside rear view mirror defogging

1

Before driving

1-1. Hybrid system

Hybrid system.....	30
Hybrid system precautions.....	34
Energy monitor/ consumption screen .....	40
Hybrid vehicle driving tips.....	45

1-2. Key information

Keys .....	47
------------	----

1-3. Opening, closing and  
locking the doors

Smart access system with push-button start .....	52
Wireless remote control.....	64
Side doors .....	67
Back door.....	70

1-4. Adjustable components  
(seats, mirrors,  
steering wheel)

Front seats.....	82
Rear seats.....	86
Driving position memory .....	90
Head restraints.....	95
Seat belts .....	97
Steering wheel.....	105
Anti-glare inside rear view mirror .....	107
Outside rear view mirrors.....	109

1-5. Opening and closing the  
windows and moon roof

Power windows.....	112
Moon roof .....	115

1-6. Refueling

Opening the fuel tank cap.....	119
--------------------------------	-----

1-7. Theft deterrent system

Immobilizer system .....	124
Alarm.....	126
Theft prevention labels (for U.S.A.).....	129

## 1-8. Safety information

Correct driving posture .....	130
SRS airbags .....	132
Front passenger occupant classification system.....	144
Child restraint systems .....	149
Installing child restraints .....	153

## 2 When driving

### 2-1. Driving procedures

Driving the vehicle .....	166
Power (ignition) switch .....	176
Hybrid transmission .....	182
Turn signal lever .....	190
Parking brake .....	192
Horn.....	193

### 2-2. Instrument cluster

Gauges and meters .....	194
Indicators and warning lights.....	198
Multi-information display.....	202
Head-up display .....	208

### 2-3. Operating the lights and windshield wipers

Headlight switch.....	213
Automatic High Beam.....	219
Fog light switch .....	226
Windshield wipers and washer .....	229
Rear window wiper and washer .....	235
Headlight cleaner switch .....	237

### 2-4. Using other driving systems

Cruise control .....	238
Dynamic radar cruise control.....	243
Intuitive parking assist .....	257
Electronically modulated air suspension .....	264
Rear view monitor system .....	270
Driving assist systems.....	274
Hill-start assist control .....	280
Pre-Collision System.....	282

**2-5. Driving information**

Utility vehicle precautions .....	286
Cargo and luggage .....	290
Vehicle load limits .....	295
Winter driving tips .....	296
Trailer towing (AWD models with towing package) .....	300
Trailer towing (2WD models and AWD models without towing package) .....	318
Dinghy towing .....	319

---

**3 Interior features**

---

**3-1. Using the air conditioning  
system and defogger**

Automatic air conditioning system .....	322
Rear window defogger switch .....	330
Windshield wiper de-icer .....	331

**3-2. Using the audio system**

Audio system .....	332
Using the radio .....	336
Using the CD player .....	346
Playing MP3 and WMA discs .....	356
Operating an iPod .....	366
Operating a USB memory .....	374
Optimal use of the audio system .....	383
Using the AUX port .....	386
Using the steering wheel audio switches .....	388

**3-3. Using the Bluetooth®  
audio system**

Bluetooth® audio system .....	391
Using the Bluetooth® audio system .....	394
Operating a Bluetooth® enabled portable player .....	399
Setting up a Bluetooth® enabled portable player .....	403
Bluetooth® audio system setup .....	410

### 3-4. Using the hands-free phone system (for mobile phones)

Hands-free system for mobile phones .....	411
Using the hands-free system (for mobile phones) .....	415
Making a phone call .....	423
Setting a mobile phone .....	428
Security and system setup .....	434
Using the phone book .....	438

### 3-5. Using the interior lights

Interior lights list .....	445
• Interior lights .....	446
• Personal lights .....	446

### 3-6. Using the storage features

List of storage features .....	448
• Glove box .....	449
• Bottle holders/door pockets .....	450
• Cup holders .....	451
• Console box .....	453
• Auxiliary boxes .....	455
• Under tray .....	456

### 3-7. Other interior features

Sun visors .....	457
Vanity mirrors .....	458
Clock .....	459
Outside temperature display .....	460
Multi-display light control .....	461
Power outlets .....	462
Seat heaters and ventilators ...	465
Armrest .....	467
Coat hooks .....	468
Floor mat .....	469
Luggage compartment features .....	470
Garage door opener .....	474
Compass .....	480
Safety Connect .....	484

**4 Maintenance and care****4-1. Maintenance and care**

Cleaning and protecting the vehicle exterior .....	492
Cleaning and protecting the vehicle interior .....	495

**4-2. Maintenance**

Maintenance requirements .....	498
General maintenance .....	501
Emission inspection and maintenance (I/M) programs .....	505

**4-3. Do-it-yourself maintenance**

Do-it-yourself service precautions .....	506
Hood .....	509
Positioning a floor jack .....	510
Engine compartment .....	512
12-volt battery .....	525
Tires .....	532
Tire inflation pressure .....	541
Wheels .....	545
Air conditioning filter .....	547
Electronic key battery .....	550
Checking and replacing fuses .....	552
Headlight aim .....	568
Light bulbs .....	571

**5 When trouble arises****5-1. Essential information**

Emergency flashers .....	590
If your vehicle needs to be towed .....	591
If you think something is wrong .....	597

**5-2. Steps to take in an  
emergency**

If a warning light turns on or a warning buzzer sounds .....	598
If a warning message is displayed .....	608
If you have a flat tire .....	629
If the hybrid system will not start .....	643
If the shift lever cannot be shifted from P .....	645
If you lose your keys .....	646
If the electronic key does not operate properly .....	647
If the vehicle 12-volt battery is discharged .....	650
If your vehicle overheats .....	655
If the vehicle becomes stuck .....	660
If your vehicle has to be stopped in an emergency .....	661

## 6 Vehicle specifications

### 6-1. Specifications

Maintenance data (fuel, oil level, etc.).....	664
Fuel information.....	676
Tire information.....	680

### 6-2. Customization

Customizable features .....	693
-----------------------------	-----

### 6-3. Initialization

Items to initialize .....	702
---------------------------	-----

## 7 For owners

Reporting safety defects for U.S. owners.....	704
Seat belt instructions for Canadian owners (in French).....	705
SRS airbag instructions for Canadian owners (in French).....	708

## Index

Abbreviation list .....	720
Alphabetical index.....	722
What to do if... ..	733